

B O M B J A C K

PARTS SIDE

+ 5V	1
+ 5V	2
	3
+ 12V	4
SPEAKER (-)	5
GND	6
GND	7
GND	8
2P START	9
COIN SW 2	10
	11
	12
1P DOWN	13
1P LEFT	14
	15
	16
2P DOWN	17
2P LEFT	18

SOLDER SIDE

1	+ 5V
2	+ 5V
3	
4	+ 12V
5	SPEAKER (+)
6	GND
7	GND
8	GND
9	1P START
10	COIN SW 1
11	
12	1P JUMP
13	1P UP
14	1P RIGHT
15	
16	2P JUMP
17	2P UP
18	2P RIGHT



1 LEVA 8 POSIZIONI
 1 PULSANTE
 TV VERTICALE

1	BLUE
2	GREEN
3	RED
4	GND
5	SYNC
6	GND

ディップスイッチ ● Dip Switch BOMB JACK

MOD. 85

DIP SWITCH 1		1	2	3	4	5	6	7	8
COIN1	1COIN - 1PLAY	OFF	OFF						
	1COIN - 2PLAY	ON	OFF						
	1COIN - 3PLAY	OFF	ON						
	1COIN - 6PLAY	ON	ON						
COIN2	1COIN - 1PLAY			OFF	OFF				
	2COIN - 1PLAY			ON	OFF				
	1COIN - 2PLAY			OFF	ON				
	1COIN - 3PLAY			ON	ON				
ジャックの数 NUMBER OF JACK	3 JACKS					OFF	OFF		
	4 JACKS					ON	OFF		
	5 JACKS					OFF	ON		
	2 JACKS					ON	ON		
タイプ TYPE	テーブル COCKTAIL TABLE							OFF	
	アップライト UPRIGHT							ON	
デモンストレーション音 DEMONSTRATION SOUND	音無 NON SOUND								OFF
	音有 SOUND								ON

DIP SWITCH 2		1	2	3	4	5	6	7	8
難易度1 (スピード) DIFFICULTY 1 (SPEED OF MECHANIC BIRD)	難 MODERATE				OFF	OFF			
	難 DIFFICULT				ON	OFF			
	難 MORE DIFFICULT				OFF	ON			
難易度2 (敵の数) DIFFICULTY 2 (ENEMIES' NUMBERS AND SPEED)	難 TOP DIFFICULT				ON	ON		ON	OFF
	難 EASY							OFF	OFF
	難 MODERATE							OFF	ON
スペシャルコイン出現率 RATIO OF SPECIAL COIN APPEARANCE	難 DIFFICULT						ON	ON	
	難 MORE DIFFICULT								OFF
	難 EASY								ON

VELOCITÀ
ACCIAI
MECANICI

NUMERO E
VELOCITÀ
MEMICI

DIFFICOLTÀ
BONUS

Con modifica MOD. 85 le difficoltà 1 e 2 aumentano di 4 gradi ed esattamente quello che nel MOD. 84 era MODERATE ora diventa TOP DIFFICULT e così via, mentre quello che era EASY ora diventa MORE DIFFICULT e così via. Rimane invariata la difficoltà BONUS.